

18C0033	CART. TINTA COLOR - LEXMARK C90/P4300/P6300
18C0034	CART. TINTA PRETO - LEXMARK C90/P6200/5200
18C0035	CART. TINTA COLOR - LEXMARK C90/P6200/5200
18S0090	CART. TONER PRETO - LEXMARK S40
24018SL	CART. TONER PRETO - LEXMARK E250/E330 - 12A8400
56P2542	CONJUNTO DO FUSOR T630/632
59P9900	KIT DE MANUTENÇÃO - LEXMARK C910(56P9900)
64018HL	CART. TONER PRETO - LEXMARK H40/642/644
C5220CS	CART. DE TONER CYAN3000 LEXMARK C52X/C522
C5220KS	CART. DE TONER PRETO4000 LEXMARK C52X/C522
C5220MS	CART. DE TONER MAGEENTA3000 LEXMARK C52X/C522
C5220YS	CART. DE TONER AMARELO3000 LEXMARK C52X/C522
C53034X	KIT FOTOCONDUTOR LEXMARK C53034X
C92035X	OLEO DE REVESTIMENTO DO FUSOR
E250A11L	TONER LEXMARK E250/B560/E362
E250A21L	TONER LEXMARK E250/B560/E362
I56P9986	CABEÇA DE IMPRESSÃO COLOR LED OPTRA C912
X340A11G	CARTUCHO DE TONER LEXMARK X340/342
X340H11G	CARTUCHO DE TONER LEXMARK X340/342
X340H22G	KIT FOTOCONDUTOR LEXMARK X340/342